

Saxo Adapter



Functions assignment

| No. | EMU pin name | Function | |
|-----|-----------------------|-------------------------|-------------------------------|
| | | Bosch M7.4.4 | Bosch ME7.4.4 / Marelli M4.8P |
| 1 | Analog In #1 | - | PPS 2 |
| 2 | Analog In #2 | AC signal | AC pressure sensor |
| 3 | Analog In #3 | Trinary switch | TPS 1 |
| 4 | Analog In #4 | - | TPS 2 |
| 5 | Switch #1 | Power steering pressure | Power steering pressure |
| 6 | AUX 1 | Main relay | Main relay |
| 7 | AUX 2 | Fan high speed | Fan high speed |
| 8 | AUX 3 | Fan low speed | Fan low speed |
| 9 | AUX 4 | Tacho | - |
| 10 | AUX 5 | MIL lamp | - |
| 11 | AUX 6 | Temp gauge | - |
| 12 | H-bridge #1 winding A | IACV | DBW + |
| 13 | H-bridge #1 winding B | IACV | DBW - |
| 14 | H-bridge #2 winding A | IACV | - |
| 15 | H-bridge #2 winding B | IACV | - |
| 16 | Ignition coil #1 | Coil cyl #1 and #4 | Coil cyl #1 and #4 |
| 17 | Ignition coil #2 | Coil cyl #2 and #3 | Coil cyl #2 and #3 |
| 18 | Injector #1 | Injector 1 | Injector 1 |
| 19 | Injector #2 | Injector 2 | Injector 2 |
| 20 | Injector #3 | Injector 3 | Injector 3 |
| 21 | Injector #4 | Injector 4 | Injector 4 |
| 22 | Injector #5 | AC clutch inhibit | - |
| 23 | Injector #6 | Temp too high indicator | - |